





Patent No.:201120133518.4


FEATURES

- · Large switch capacity up to 40A
- · Green Energy Saving

CONTACT RATINGS

Contact Arrangement	1A、1C
Contact Resistance	50mΩ(1A 24VDC)
Contact Material	AgSnO, Silver Alloy
Contact Rating(Resistive)	30/40A 277VAC 30A/28VDC
Max. Switching Voltage	277VAC/28VDC
Max. Switching Current	40A
Max. Switching Power	7200VA/560W
Mechanical Life	1×10 ⁷ times
Electrical Life	1×10⁵ times

ORDERING INFORMATION



Note: This relay do not have pin 6.

CHARACTERISTICS

		(, , , , , , , , , , , , , , , , , , ,	
Insulation Resistance		1000MΩ (at 500VDC)	
Dielectric Strength	Between coil & contacts	2000VAC 1min	
	Between open contacts	1500VAC 1min	
Reacting time (at nomi. volt.)		15ms max.	
Resetting time (at nomi. volt.)		10ms max.	
Humidity		98% RH,40°C	
Ambient temperature		-20°C ~ +85°C	
Shock Resistance	Functional	98m/s ²	
	Destructive	980m/s ²	
Vibration resistance		10Hz to 55Hz 1.5mm DA	
Unit weight		Approx. 26g	
Construction		Sealed, Covered	

COIL DATA

at 25°C

Nominal Voltage VDC	Action/Reset Voltage VDC	Impulse Width ms	Coil Resistance Ω±10%
5	4.0	100	21
6	4.8	100	30
9	7.2	100	67.5
12	9.6	100	120
24	19.2	100	480
48	38.4	100	1920

COIL

Coil Power	1200mW
------------	--------

Notes: The data shown above are initial values.

This datasheet is for customers' reference. All the specifications are subject to change without notice.



TEL:(516) 328-9292 FAX:(516)326-9125 www.hascorelays.com email:info@hascorelays.com

SAFETY APPROVAL RATINGS


UL&CUL	NO	1HP/120VAC, 2HP/277VAC, 2HP/240VAC 20A/277VAC Ballast, 30A/120VAC Ballast
	NC	2HP/277VAC, 1HP/120VAC 10A/277VAC Ballast, 2A/120VAC Tungsten

OUTLINE DIMENSIONS, WIRING DIAGRAM AND PC BOARD LAYOUT.

Unit: inch(mm)

Outline Dimensions

PCB Layout (Bottom view)



Remark:1) In case of no tolerance shown in outline dimension: outline dimension ≤1mm,tolerance should be ±0.2mm; outline dimension >1mm and ≤5mm,tolerance should be ±0.3mm;outline dimension >5mm, tolerance should be ±0.4mm.

2) The tolerance without indicating for PCB layout is always ±0.1mm.

Notice

- 1.Relay is on the "reset" or "set" status when being released form stock, with the consideration of shock risen from transit and relay mounting, relay would be changed to "set" or "reset" status, therefore, when application (connecting the power supply), please reset the relay to "set" or "reset" status on request.
- 2.In order to maintain "set" or "reset" status, energized voltage to coil should reach the rated voltage, impulse width should be 5 times more than "set" or "reset" time. Do not energize voltage to "set" coil and "reset" coil simultaneously. Long energized time (more than 1 min) should be avoided.

This datasheet is for customers' reference. All the specifications are subject to change without notice.



TEL:(516) 328-9292 FAX:(516)326-9125 www.hascorelays.com email:info@hascorelays.com